

1. Posizionare la dima (o le dime a seconda della composizione che si vuole realizzare) sulla parete nella posizione in cui si desidera appendere lo specchio.
2. Forare la parete nei punti indicati dalla dima
- N.B.** I fori devono avere un diametro di 8mm ed una profondità minima di 40mm.
3. Inserire i tasselli in nylon all'interno dei fori appena eseguiti.
4. Avvitare i gancetti in acciaio all'interno dei tasselli, finchè non sporgano all'esterno più di 10mm.
5. Agganciare lo specchio facendo coincidere i fori dello stesso con i due supporti.

1. Place the template (or the templates according to the desired composition) in the position to hang the mirror.
2. Bore the wall in the points indicated by the template.
- PLEASE NOTE:** The holes shall have a 6mm diameter and a minimum depth of 40mm.
3. Place the nylon expansion bolt inside the above mentioned holes.
4. Screw the steel hooks into the expansion bolt until they jut out for no more than 10mm.
5. Hook the mirror in order that its holes coincide with the two relevant supports.

